

Official Instruction Manual

A-Bar / Nudge Bar Subaru Crosstrek 2013-2017
Part Number: DCSU-665-32



Place bracket up to front tow hooks and slide spacer and bolt through to successfully mount the front 2 brackets



When each side is mounted you have successfully mounted the brackets.